


Direction-Control Valve (manual operation)


Hydraulic Valves

HOV-43 (H·P·C·T)、HOV-44 (H·P·C)




Note 1 :This port is only processed to HOV-43T and HOV-44 (H/P/C), and 43T is the DR port and 44 (H/P/C) is the T port.
Note 2 :This port is only processed to HOV-43 (H/P/C). The dimensions in brackets show that of HOV-44 (H/P/C).

HOV-44 T



※DR and the bottom T port are Rc3/8.

HOV-48 (H·P·C)



Change valve with flange (HOV-43/44 only)

