

Large-Size Modular Valve

■ List of the models

Item name	Type			Remarks
	For MP-15	For MP-17	For MP-20	
Solenoid valve	SOW-R-4※-※ (1) (2)	SOW-R-46※-※ (1) (2)	SOW-R-48※-※ (1) (2)	(1) Spool type at neutral (2) AC 100 V and 200 V are displayed as 1 and 2.
Manual change valve	BHV-44-※	BHV-46-※	BHV-48-※	※Type at neutral
Change plate for solenoid valves (exclusive to large-size modular valves)	BSS-4	BSS-6	BSS-8	
Pilot controlled check valve	BCH-44-※	BCH-46-※	BCH-48-※	※The AB line is displayed as AB and the B line is displayed as B.
Relief valve	BRV-4-※	-	-	※The P line is displayed as P and the AB line is displayed as AB. The valves for A and B are also available.
Counter balance valve	BCB-4B	BCB-6B	BCB-8B	The pressure control range is between 2 MPa and 10 MPa. In normal, the internal pilot is set.
Outlet	BPS-41	BPS-61	BPS-81	Mounted directly to the pump
	BPS-42	BPS-62	BPS-82	For piping

For MP-15



For MP-20

